User's Manual



Overview	2
User Manual	2
1. Unlocking Modes	2
2. Setting the master card	2
3. How to add the user card	2
4. Unlocking	2
5. Other features	વ

Overview

The RF-202 can be used for locking cabinet/drawer.

User Manual

Step 1: Mode Selection

- Use a long pin or needle to press the reset for 1 second.
- After 1 beep and 5 single beeps single mode
- Use a long pin or needle to press the reset for 2 seconds
- After 1 beep, and 5 double beeps dual mode (Note: Dual mode requires two cards to allow access)

Step 2: Master Card

• The first and second cards added are the master cards

Step 3: User Card

- Show the master card, wait for a single beep
- Use a new card after this, user card is enabled

Step 4: Unlocking

Single Mode

- Show the card and wait for a beep
- After 2 beeps, the lock automatically releases, can pull the drawer open
- When you close the drawer, it will lock automatically

Dual Mode

- Show a user card and wait for a beep, then show a second user card
- After 2 beeps, the lock automatically releases, can pull the drawer open
- When you close the drawer, it will lock automatically

NOTE: You can only add up to 13 user cards and 2 master cards

www.auruslocks.com

Other features:-

- The master card can set different locks
- In case of Low Battery, there will be 8 beeps when opening the drawer, and the lock will remain open after that even if you try to shut the drawer again. Replace battery immediately in this case.

all Kus