


FINGERPRINT CABINET LOCK

USER MANUAL



Automatic Mode

1. How to add new fingerprints

- Put a registered finger on sensor, after green light the latch retracts, keep on holding, remove after green light is on
- Blue light, put a finger on, remove after green light
- Put the finger on, green light then remove; repeat until a long green light for 3 seconds (The fingerprint is registered)
- Blue light, add more new fingerprints



Step 1

Note

- 1). Make sure to add a fingerprint before using. Any finger can unlock in the factory setting
- 2) In order to keep the lock in good working condition, add no less than 3 fingerprints

2. How to delete fingerprints

- Put any registered finger on sensor, green light, holding, green light again, keep holding, green light then red light flashed, then remove
- green light for 3 seconds, all the fingerprints deleted



3. How to lock

- Push the door closed, door lock automatically

4. How to unlock

- Put any registered fingerprint on sensor
- Green light, unlocked
- Pull the door open

Other Function

E-Key

- 1.Insert E-Key
- 2.Put any finger on sensor, green light on, unlocked
- 3.Pull the door open



2. Low battery warning

- In case of low battery, put the registered fingerprint, green light flashes once, and red light flashes thrice, then a long green light, then it will be unlocked. Change the battery immediately after door open
 Note: Use 3XAAA alkaline battery, do not use Carbon battery

3. Outer Power Supply

- When low battery, can connect power bank or mobile plug for outer power supply
 After unlocked, change the battery immediately



4. TUYA app bluetooth version


Please open the TUYA App for details.

Feature

1. Biometric sensor, highly sensitive and rapid response
2. Max 30 fingerprints can be added
3. E-Key for emergency and management
4. Material: Zinc-alloy, automatic locking system
5. Surface mounted, widely used in drawer, cabinet, wardrobe etc.

Installation Instructions

1. Put the installation drawing on the door, approx 45mm between the door frame and centre hole (Picture 1), then drill the hole




Picture 1

wire connection



	Door Thickness (mm)		Screw
	1	14mm-16mm	M4X20
2	16mm-18mm	M4X22	
3	19mm-21mm	M4X25	

2. Wire goes through the center hole and fix the front panel by screw M4X22, then connect the back lock. (Tide up the wire not cross), fix back lock by crew ST3.SX18



Picture 2

3. Fix the striking plate by screw ST3.SX18 (Make sure latch works well)



Picture 3

COMPONENT



INSTALLATION DRAWING



Follow the drawing to drill the hole